



Optimum Performance Products
1927 Boblett Street
Blaine, WA, USA
1-877-942-6744 Toll Free
1-604-942-6744 International
info@oppracing.com
www.oppracing.com

Mounting Instructions
Ducati 848 / 1098 / 1198 Keylock Cover

Part # 035795 (Carbon Fiber)
035796 (Texalium)

The immobiliser must be fitted with attached single sided glued foam.
Cut it to appropriate sizes and use two layers of it to make 4 pads for fixing immobiliser.



It is also important how immobiliser is rotated – therefore please take care and mount it as originally attached.



Wrong position of fitting.
Take care, the immobiliser should be fixed less than 10mm below the upper edge of keylock!!
If it is lower, the warning light will pop out!



If not correctly fitted, the yellow error light goes ON at engine start-up



Final fitting of keylock cover.

