

AS SEEN IN 2 WHEEL TUNER MAGAZINE!
FOR MORE INFO VISIT WWW.SPORTBIKECLUB.COM



D.I.Y.

DRIVEN GRIPS



1. Remove the bar ends with the appropriate tools needed.



2. Use an X-Acto knife to cut off the old grips.



3. Check the (right side) throttle tube for any ridges. If there are any, they must be removed using a dremel tool.



4. Place a small amount of WD-40 between the D3 rings and the krayton gel grip. Clean the left and right side of any dirt or old glue.



5. Using an air compressor and hose, install the grip while using the air to expand and move the grip onto the bar.



6. After both grips have been successfully installed, re-install your bar ends. Let grips sit for at least 1 hour in order for the WD-40 to evaporate. You are finished.

Tools used: air compressor, WD-40 or other similar lubricant, X-Acto knife, Latex gloves (optional), dremel tool, screwdriver (optional), grip glue (optional)

TIME: 30-40 minutes **DIFFICULTY:** easy **RETAIL PRICE:** \$49.95
Installed by Noam Avraham

www.drivenracing.com 818-996-1407

***DRIVEN REQUIRES THIS PRODUCT TO BE INSTALLED BY A CERTIFIED TECHNICIAN.**