



GILLES TOOLING KG

VarioBar

Anbauanleitung / installation manual

ABK-SC 33-AL

Montage Ausleger Kit
Installation extension kit
Honda CBR 900
SC 33 Bj '98-'99

1. Obere Gabelbrücke, Lenkergewichte, Armaturen und Originallenker abschrauben.
2. Kabelband lösen (A), Signalhornkabel mit KBL 80 (B) verlängern (Bild 1)
3. Kupplungszüge unter Instrumentenhalter verlegen (Bild 2/Pfeil)
4. Verdrehsicherung am Halter Bremsflüssigkeitstank und Bremszylinder sauber abschneiden (Bild 3 und 4 /Pfeil)
5. VarioBar montieren wie in Anleitung „Basis Kit“ beschrieben.
6. Ausleger montieren wie in Anleitung „Ausleger Kit“ beschrieben (Bild 5).

Abschließend Bremse neu entlüften

1. Dissmantle upper yoke, handle bar weights, instruments and the original handle bar.
2. Detach cable holder (A), lengthen horn cable adapter with KBL 80 (B) (pic1)
3. Detach the hose clamp from the chassis and lay the hose as in picture 2.
4. Cut cleanly the rotary lock (pic 3,4, arrow) from holder of brake fluid reservoir and from brake cylinder.
5. Install the VarioBar as described in manual “basis kit”
6. Install the extension as described in manual “extension kit” (pic 5).

Finally bleed the brake.

Abschließend kontrollieren ob alle Züge und Leitungen freigängig sind und nirgends scheuern.

Finally be cautious that all wires and cables have enough space room to other components and do not .

