


# Teileliste/partlist KTS-RP12-\*



vers.004 / 04



kts.chain adjuster



Pos	Art.bezeichnung / part name	Teilenr. / part no.	Menge / Qty	
1	Etikett / label	KTS-RP12-*	1	Verpackung
2	Karton / cardboard box		1	Verpackung
3	Anleitung / manual	ABA-KTS2	1	Verpackung
4	<b>Zusatzanl. / additional manual</b>	<b>add. manual KTS-RP</b>	<b>1</b>	<b>Beipack</b>
5	Teilelist / part list	part list KTS-RP12	1	Verpackung
6	Einleger / inlay		1	Verpackung
7	Führung links / guidance left	KTS-FU-RN09-*	1	Kettenspanner
8	Führung rechts / guidance right	KTS-FU-RN09-*	1	Kettenspanner
9	Slider links / slider links	KTS-SL07-L-*	1	Kettenspanner
10	Slider rechts / slider rechts	KTS-SL07-R-*	1	Kettenspanner
11	<b>Gegenhalter / counter part</b>	<b>KTS-GGH07-*</b>	<b>2</b>	<b>Beipack</b>
12	Stellschraube / adjusting screw	KTS-STS-45	2	Kettenspanner
13	Spannstift / split pin	SS3x14	4	Kettenspanner
14	Scheibe / collar	GTM-0815-005	2	Kettenspanner
15	<b>Scheibe / collar</b>	<b>DS39-28,4-6</b>	<b>1</b>	<b>Beipack</b>
16	Schraube / screw	M6x25 ISO7380	4	Beipack
17	Schraube / screw	M6x30 DIN7991	4	Beipack
18	Schraube / screw	M8x16 ISO7380	2	Beipack