


vcr38gt-H03

teilleiste / partlist



Pos.	Description	Part-No.	Qty.
1	left rotor plate	VCR-GL-H03-*	1
2	right rotor plate	VCR-GR-H03-*	1
3	rotor	VCR-RT-01-*	4
4	left slider	VCR-SL-01-*	1
5	right slider	VCR-SR-01-*	1
6	holder brake unit	VCR-BU-06-*	1
7	holder shift unit	VCR-SU-01-*	1
8	excenter	VCR-EX-01-*	1
9	footrest	UF-04-*	2
10	plug	7 702 856	2
11	left heel protector	CAR01-L	1
12	right heel protector	CAR01-R 6,5-49	1
13	brake lever	UB-10-*	1
14	brake lever toe piece	UTR01-*	1

Pos.	Description	Part-No.	Qty.
15	holder exhaust	UAH05-B	1
16	rubber exhaust	80103-MG2-000	1
17	gear lever	US-10-*	1
18	gear lever toe piece	UTR06IT-*	1
19	gear lever roller	UTR05	1
20	gear lever adapter	SPS04	1
21	gear shaft	USW09-*	1
22	stopp light switch	01022.4501-01	1
23	spring brake lever	7 699 626	1
24	spring fixing pin	7 702 868	1
25	brake cylinder adapter	UAD02-23	1
26	adapter pin	FKB6x12	1
27	connector	01-0110058	2
28	screw	M6x16-7991-VA	2

vcr38gt-H03
teileliste / partlist



Pos.	Description	Part-No.	Qty.
29	screw	M8x40-7991-VA	2
30	screw	M8x55-7991-VA	1
31	screw	M4x6-912-VA	1
32	screw	M6x16-912-VA	1
33	screw	M8x20-912-VA	4
34	screw	M8x25-912-VA	1
35	screw	M8x60-912-12.9-*	2
36	ball and socket bearing	GAKFL6	1
37	ball and socket bearing	GAKFR6	1
38	washer	ULS6,4	2
39	washer	ULS8,4	2
40	gear arm	SA03-*	1
41	bind	BL01-*	1
42	screw	M5x8-7380-VA	2

Pos.	Description	Part-No.	Qty.
43	screw	M6x16-7380-VA	1
44	screw	M6x20-7380-VA	1
45	screw	M6x25-7380-VA	2
46	screw	M6x30-7380-VA	1
47	screw	M6x60-7380-VA	1
48	screw	M8x25-7380-VA	1
49	nut	M6-985-VA	3
50	nut	M8-439-VA	1
51	collar	DS11-6-14	3
52	collar	DS14-6-4	1
53	collar	DS12-8-12	1
54	collar	DS20-8-8	1
55	collar	DS20-8-12	1
56			