



as31gt-K09A

teileliste / partlist



Pos.	Description	Part-No.	Qty.
1	left basic plate	K09GL-*	1
2	right basic plate	K09GR-*	1
3	left adjusting plate	UV01L-*	1
4	right adjusting plate	UV01R-*	1
5	gear lever	US02-*	1
6	brake lever	UB02-*	1
7	gear lever bearing	UL01L-*	1
8	brake lever bearing	UL01R-*	1
9	left heel protector	CAR01-R-6-40	1
10	right heel protector	CAR01-R-8-49	1
11	footrest	UF04-*	2
12	plug	7 702 856	2
13	holder brake cylinder	UHB27-*	1
14	gear lever toe piece	UTR02-*	1
15	brake lever toe piece	UTR01-*	1
16	gear shaft	USW02-*	1
17	adapter gear shaft	USWAD01-*	1
18	gear arm	SA01-*	1
19	ball and socket bearing	GAKFR6	1
20	ball and socket bearing	GAKFL6	1
21	holder stopp light	BLS04	1

Pos.	Description	Part-No.	Qty.
22	brake cylinder adapter	UAD02-23	1
23	adapter pin	FKB6x12	1
24	spring	FE30	1
25	nut	M6-985	1
26	screw	M5x8-7380	2
27	screw	M6x20-7380	1
28	screw	M6x25-7380	1
29	screw	M8x20-7380	6
30	collar	DS12-6-9	1
31	collar	DS15-6-6	2
32	collar	DS20-8-6	4
33	screw	M5x10-7991	1
34	screw	M6x16-7991	2
35	screw	M6x20-7991	2
36	screw	M6x45-7991	1
37	screw	M8x25-7991	4
38	screw	M8x40-7991	2
39	washer	ULS6,4	1
40	washer	ULS8,4	4
41	screw	M5x25-912	1
42	holder	HA05-B	1